

## PERFECT FOR GROWING STRAWBERRIES WITH AUTOPOT

DESIGNED TO FIT 8.5 L POTS AS USED IN EASY2GROW

FOLIAGE GROWS UP, FRUITS HANG DOWN - FOR EASE OF ACCESS





Fits 8.5 L / 2.2 gal pots as used in easy2grow modules (pictured above)

USA / CANADA



REST OF WORLD



@AUTOPOT\_GLOBAL









# IDEAL FOR MODULES ON SHELVES OR ELEVATED RACKING

# **strawberry fopper**

## ALLOWING FRUITS TO HANG MAKES INSPECTION EASIER

## FITS 8.5 L / 2.2 GAL POTS AS USED IN EASY2GROW

#### **COMPATIBLE WITH:**

CONTENTS:

· AutoPot 8.5 L / 2.2 gal Pots

#### POTS AS USED IN:

- · easy2grow Modules
- · Auto8 Modules



1x Strawberry Topper



Prepare your pots with root control as usual.

Put marix or root control discs (not supplied) into your 8.5L / 2.2 gal pots (not supplied).



With the pots outside the module tray sit Strawberry Toppers directly onto the pot rims



Fill pots with media to just below lower lip of Strawberry Topper



Lay strawberry plants side-on.



Top strawberry plants off with a little extra media.

Water through pots and allow to drain outside tray.



Complete module set up as per module instructions.

Once drained place pots into your module tray.